




REC 15 AC1



REC 15 AC1, backpack sprayer (15 litres) with battery pack, with charger EU		12070901	220154
REC 15 AC2, backpack sprayer (15 litres) without battery pack, without charger		12073001	220192
REC 15 AC5, backpack sprayer (15 litres) with battery pack, without charger		12139201	038148
Accessories (Pictures see page 78 ff)			
AS 1200 AC1, battery spray blower (only REC 15)		12118001	014319
Vario Gun, stepless variable one-hand operation from spray to jet		11558501	100821
Floodjet nozzle 1.6 mm (blue) (Herbicide nozzle)		10501803-SB	100241
XL 8 S Telescopic lance 7 m (max. 6 bar) / working height 8 m (Spray version)		11935801	113982
Telescopic tube 1- 2 m, anodised aluminium, thread G1/4"e on both sides		10985201	100456
Professional spray hood oval, screw fitting		10501606	100906
Spray hood, 12.5 cm, screw fitting		11998601	710891
Spray boom, aluminium, screw fitting, 4 fanjet nozzles XR 11001 VS (orange) for REB / REC		12033001	720845
Duro mist nozzle 1.65 mm, brass - for white washing and special applications		28502325-SB	100364
Biofilter for the use of home-made spray mixtures		11475701	100593
Gasket set, No 2,9,10,15,20,31,33,36,37	REC / REB	11934101	113876
Gasket set spraying equipment, No 23,24,25,26,27,29,31,33	REC	12058001-SB	150260
Nr. Spare parts			
1 Lid ø137 mm	REC / REB	10397202-SB	151007
3 Filter screen	REC / REB	77009699-SB	151038
4 Carrying belt (pair)	REC / REB	11923401	113722
5 Electronic	REC	12076201	150970
5 Electronic	REB	12075901	151083
6 Potentiometer knob, minimum order qty. 5 pcs	REC / REB	11922701	720838
7 Battery fixing plate	REC	12075601	150994
7 Battery fixing plate	REB	12075501	151106
8 Motor cover complete	REC	11948701	200101
11 Suction tube	REC	12078501	151380
12 Pump and motor	REC	11923002	210322
12 Pump and motor	REB	12017801	720463
13 Diaphragm and pulsation damper set	REC	11998301	710884
14 Air vessel	REC	11933302	210346
14 Air vessel	REB	12071501	151113
16 Spray tube holder	REC / REB	11934001	113951
17 Hose 1.3 m, G1/2"-G1/2"	REC / REB	10396008-SB	113012
19 Trigger Profi G1/2"	REB	11934701	113784
Gasket set for trigger	REB	11664910	040851
20/29 Gasket 12.2x7x3; 12 pcs per pack	REB / REC	11642404	040042
21 Trigger brass LB, G1/2", 10 bar	REC	12047501-SB	150048
22 Plastic handle G1/2"	REC	10392201-SB	100944
28 Lever for trigger brass LB	REC	12046501	150116
30 Spray tube 60 cm curved, brass	REB / REC	12007401	720074
31 Gasket 17x12.7x2; 10 pcs per pack	REB / REC	11642403	040035
32 Adjustable nozzle 1.7 mm, brass	REB / REC	28502597-SB	100777
34 Battery pack 18 V Li-Power / 4.0 Ah *	REC	12071401	150895
34 Battery pack 18 V Li-Power / 2.0 Ah *	REB	12070301	150871
35 Quick charger ASC 55, 220-240 V, EU - plug type C *	REC	12070101	150864
35 Charger SC 30, 220-240 V, EU - plug type C *	REB	12074501	150949

* Further information about the battery packs (2.0 - 10.0 Ah) and chargers, see page 8 / 79 / 80